ELECTRICAL SYMBOLS

SYMBOL	DESCRIPTION
FLUORESCENT FIXTURE	
TROUGH LIGHT (DOUBLE SOURCES FADE)	
INCANDESCENT FIXTURE	
JUNCTION BOX	
DUPLEX RECEPTACLE	
SINGLE RECEPTACLE	
SPECIAL RECEPTACLE	
QUADRUPLEX RECEPTACLE	
SPECIFIED RECEPTACLE	
ISOLATED GROUND/SPEC NEUTRAL RECEPT	
TELEPHONE OUTLET	
DATA OUTLET	
TELEVISION OUTLET	
SINGLE POLE SWITCH	
TWO POLE SWITCH	
THREE-WAY SWITCH	
FOUR-WAY SWITCH	
DIMMER SWITCH	
PILOT LIGHT SWITCH	
SINGLE THROW NORMAL SWITCH	
300W SWITCH	
KEY OPERATED SWITCH	
BUZZER	
BELL	
PUSHBUTTON (MOMENTARY)	
PUSHBUTTON (START-STOP)	
MOTOR	
DISCONNECT SWITCH	
MOTOR STARTER	
COMBINATION MTR. STARTER & DISC. SWITCH	
TELEPHONE BACKBOARD	
PANELBOARD (480V.)	
PANELBOARD (208V.)	
EMERGENCY BATTERY PACK	
COMBINATION HEAT/ALARM DETECTOR	
FIRE ALARM PULL STATION	
FIRE ALARM AUDIO-VISUAL DEVICE	
F. A. PULL STATION W/ PROTECTIVE COVER	
DUCT IONIZATION DETECTOR	
FIRE ALARM TAMPER SWITCH	
FIRE ALARM FLOW SWITCH	
TRANSFORMER	
HVAC TEMPERATURE SENSOR	
THERMOSTAT REMOTE SENSOR	
CONDUIT UP, CONDUIT DOWN	
CONCEALED CIRCUITRY BURIED OR IN SLAB	
CIRCUITRY IN WALL OR CEILING	
CONDUIT HOMERUN TO PANEL	

NOTE: NOT ALL SYMBOLS MAY APPEAR ON DRAWINGS.

KITCHEN ELECTRICAL ROUGH-IN SCHEDULE

KEY	QTY	EQUIPMENT NO.	VOLT	PHASE	W	L	CONDUIT SIZE	CIRCUIT NO.	REMARKS
A1	1	REFRIGERATOR/ICE MAKER	120	1	—	—	3/4"	20A/1P	
A2	1	DISHWASHER	120	1	—	—	3/4"	20A/1P	
A3	1	GARBAGE DISPOSAL	120	1	—	—	3/4"	20A/1P	
A4	1	TRASH COMPACTOR	120	1	—	—	3/4"	20A/1P	
A5	1	RANGE HOOD	120	1	—	—	3/4"	20A/1P	
A6	1	MICROWAVE OVEN	120	1	—	—	3/4"	20A/1P	
A7	1	COOKTOP	208	1	—	—	3/4"	30A/2P	
A8	1	WALL OVEN	208	1	—	—	3/4"	30A/2P	
A9	1	WARMING DRAWER	120	1	—	—	3/4"	20A/1P	
A10	1	COFFEE MAKER	120	1	—	—	3/4"	20A/1P	
A11	1	TOASTER OVEN	120	1	—	—	3/4"	20A/1P	
A12	1	BLENDER	120	1	—	—	3/4"	20A/1P	
A13	1	FOOD PROCESSOR	120	1	—	—	3/4"	20A/1P	
A14	1	MIXER	120	1	—	—	3/4"	20A/1P	
A15	1	JUICER	120	1	—	—	3/4"	20A/1P	
A16	1	CAN OPENER	120	1	—	—	3/4"	20A/1P	
A17	1	KNIFE SHARPENER	120	1	—	—	3/4"	20A/1P	
A18	1	WATER HEATER	120	1	—	—	3/4"	20A/1P	
A19	1	WATER FILTER	120	1	—	—	3/4"	20A/1P	
A20	1	WATER SOFTENER	120	1	—	—	3/4"	20A/1P	
A21	1	WATER PURIFIER	120	1	—	—	3/4"	20A/1P	
A22	1	WATER DISPENSER	120	1	—	—	3/4"	20A/1P	
A23	1	ICE MAKER	120	1	—	—	3/4"	20A/1P	
A24	1	WINE COOLER	120	1	—	—	3/4"	20A/1P	
A25	1	BEVERAGE COOLER	120	1	—	—	3/4"	20A/1P	
A26	1	WARMING DRAWER	120	1	—	—	3/4"	20A/1P	
A27	1	WARMING TRAY	120	1	—	—	3/4"	20A/1P	
A28	1	WARMING PLATE	120	1	—	—	3/4"	20A/1P	
A29	1	WARMING LAMP	120	1	—	—	3/4"	20A/1P	
A30	1	WARMING LAMP	120	1	—	—	3/4"	20A/1P	
A31	1	WARMING LAMP	120	1	—	—	3/4"	20A/1P	